SEGMENTS (Chapter 7 in *Computer Graphics*)

- Segment Concepts
- Segment Files
- Segment Attributes
- Multiple Workstations

Segment Concepts

- efficient to define and modify a picture as a set of subpictures
- a segment is a set of output primitives that are joined for modification purposes
- segment commands
 - create segment (id)
 - close segment
 - delete segment (id)
 - rename segment (id old, id new)
- example:
 - delete segment (6);
 - create_segment (6);

```
polyline (n, x, y);
text (xt, yt, "graphics");
```


- close segment;
- rename_segment (6, 9);

Segment Concepts, continued

- sometimes provided
 - copy_segment (id) (into an open segment)
- generally not provided
 - reopen_segment (id)
 - append_to_segment (id)


Segment Files

- a segment file is any list of segments maintained by a graphics system
- segment files often are stored as linked structures




Segment Files, continued

- several forms
 - a segmented display file is a display file program for a simple vector system




 a pseudo display file contains segment definitions from which appropriate bits in the frame buffer are set



memory management for segment storage

- blocks must be assigned as segments are created
- blocks must be returned to the storage pool as segments are deleted
- options
 - fixed-size blocks
 - easy to manage
 - lead to fragmentation
 - variable-sized blocks
 - avoid fragmentation
 - more memory management

segment format



• make changes only at the end of the refresh cycle

Segment Attributes


- visibility
 - set_visibility (id,v)
 v = visible (posted) or invisible (unposted)
- priority
 - set_segment priority (id,p)
 - used for raster-scan systems
- highlight
 - set_highlight (id,h)
 h = highlighted or normal
- size, position and orientation
 - set_segment_transformation (id,matrix)

Segment States

- a segment can be
 - painted
 - unpainted

avoiding repeated window-to-viewport mappings

- convert from world coordinates to normalized device coordinates
- transform in normalized device coordinates
- clip against viewport boundaries
- store in a refresh file or refresh frame buffer



Multiple Workstations

- each output device is identified with a unique workstation number
- controlling the display of segments is accomplished by activating and deactivating workstations

```
example activate_workstation (5); create_segment (12);
close_segment; activate_workstation (2); create_segment (13);
deactivate_workstation (5);
```

Multiple Workstations, continued

- additional commands
 - clear_workstation (ws)
 - delete_segment_from_workstation (ws, id)
 - redraw segments on workstation (ws)
 - when an overlapping segment is erased, this command restores the overlapped segments on raster-scan systems
 - copy_segment_to_workstation (ws, id)

long-term storage

- a metafile is a file used for long-term storage of graphical information
 - used by several graphics packages

SEGMENTS

- Segment Concepts
- Segment Files
- Segment Attributes
- Multiple Workstations